

“QD” BUSHING PROPER WRENCH TORQUE

TIGHTENING “IMPORTANT”

Tighten screws evenly and progressively. Never allow the sheave to be drawn in contact with the flange of the bushing. If extreme screw tightening forces are applied, excess pressures will be created in the hub of the mounted sheave which may cause it to crack.

PROPER WRENCH TORQUE TO TIGHTEN SCREWS

Bushing Size	Screw size Inches	Torque Wrench Ft-Lbs	Open end or socket wrench		Torque Capacity In-Lbs
			Length Inches	Pull (LBS)	
L	1/4	6	4	18	1,200
JA	# 10	5	4	15	1,000
SH	1/4	9	4	27	3,500
SDS-SD	1/4	9	4	27	5,000
SK	5/16	15	6	30	7,000
SF	3/8	30	6	60	11,000
E	1/2	60	12	60	20,000
F	9/16	75	12	75	30,000
J	5/8	135	15	108	45,000
M	3/4	225	15	180	85,000
N	7/8	300	15	240	150,000
P	1	450	18	300	250,000
W	1 1/8	600	24	300	375,000
S	1 1/4	750	30	300	625,000



SET SCREW TIGHTENING TORQUES AND AXIAL LOADS

Set Screw Size	Socket / Allen Key Size (Across Flat)	Recommended Tightening Torque		Set Screw Axial Load (± 30%)			
		Newton - Meter (Nm)	LBF - Inches	Cup Point		Knurled Point	
				Newtons (N)	LBF	Newtons (N)	LBF
#10 - 24	3/32	3.62	32	1500	340	2225	500
1/4 - 20	1/8	6.8	60	2500	560	3650	820
5/16 - 18	5/32	12.4	110	3500	785	5110	1150
3/8 - 16	3/16	22.6	200	4500	1010	6580	1480
1/2 - 13	1/4	45.2	400	9000	2025	13230	2975
5/8 - 11	5/16	97.2	860	12000	2720	17800	4000

Note: For axial loads in excess of the values listed, a shouldered shaft against the face of the inner ring is recommended.